

Nilfisk FOOD Nommo

foam / rinse / sanitize unit

Clean & sanitize small to medium spaces with the water-driven Nommo. Three functions in one unit save space and simplify the sanitation process.

- water-powered – requires 29-80 psi (2-6 bar) incoming water pressure
- draws from two concentrated products, one at a time – color coded selector valve matches chemical suction lines
- spray or foam – switch function by swapping nozzles
- patented Tornado rinse/spray nozzle – high-impact output with 20% less water
- Top Jet foam nozzle – creates visible, wet foam without compressed air
- simple installation & operation

NF-NOMMO – FOAM / RINSE / SPRAY



CHEMICAL MANAGEMENT & APPLICATION EQUIPMENT

Nilfisk FOOD
Authorized Distributor

foamit.com | 616 656 9225